



## 2011 FORD MUSTANG V6,V8 X-PIPES FOR FULL LENGTHS PART# 1461,1462,1655,1658

### INSTALLATION INSTRUCTIONS

**TOOLS REQUIRED**-13, 15mm sockets, ratchet, ¼" wrench, 22mm wrench.

- STEP 1** Disconnect negative battery cable.
- STEP 2** With BBK Full Length headers (**part #'s 1642/0/5 or 1633/0/5**) installed, lift X-pipe in place.
- STEP 3** Line up rear of X-pipe with stock barrel style clamps and slip clamps over reduced end of X-pipe.
- STEP 4** Position X-pipe collector flanges up to headers, connect headers and X-pipe with studs supplied in the header kit.
- STEP 5** Adjust position of exhaust system for fitment and clearance. Tighten clamps and collector nuts.
- STEP 6** Remove rear O2 sensors from the stock midpipes.
- STEP 7** Install rear O2 sensors in the BBK X-pipe.
- STEP 8** Connect supplied O2 sensor extension wires to plugs at wire harness at the side of the trans. Connect the sensors.
- STEP 9** Start engine and check for any exhaust leaks.



***X-pipe shown installed  
Connects to stock rear barrel-style clamps***

[www.BBKPERFORMANCE.com](http://www.BBKPERFORMANCE.com)

CLICK TO VISIT

**IMPORTANT-** All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.